

# ThermaCheck Plus Thermometer

## in a robust IP66/67 waterproof case

- backlight, auto-off, max/min & hold functions
- integrated rubber seal for durability
- minimum 5 years battery life
- 2 year guarantee

The ThermaCheck Plus is a waterproof, hand held thermistor thermometer which offers IP66/67 protection and is housed in a robust waterproof white ABS case. The thermometer utilises state of the art electronic circuitry, designed for reliability and ease of use and can be submerged or washed under a running tap - ideal for food processing applications where cleaning is paramount.

Measuring temperature over the range of -39.9 to 149.9 °C with a 0.1 °C resolution, the ThermaCheck Plus features a large, easy to read, LCD display with max/min, °C/°F, hold, open circuit, low battery indication and an optional backlight. The unit also incorporates an auto-power off facility that automatically turns the instrument off after ten minutes, maximising battery life.

The instrument is housed in an ergonomic, ABS case that includes 'Biomaster' additive which reduces bacterial growth. Each unit has an integrated rubber seal to ensure complete water resistance and help reduce the possibility of damage in harsh environments.

The ThermaCheck Plus is supplied complete with a permanently attached food penetration probe with a 130 mm stainless steel stem and one metre coiled PU lead.



### optional accessories

- protective silicone boot, wide range of colours available - see below for details
- anti-bacterial wipes - see page 35



order code	description	£ each
232-042	ThermaCheck Plus	95.00
830-231	protective silicone boot - white	7.00
830-232	protective silicone boot - yellow	7.00
830-233	protective silicone boot - green	7.00
830-234	protective silicone boot - red	7.00
830-235	protective silicone boot - blue	7.00
830-257	protective silicone boot - black	7.00
832-015	stainless steel wall bracket	10.00

specification	ThermaCheck Plus
range	-39.9 to 149.9 °C
resolution	0.1 °C
accuracy	±0.4 °C (-10 to 70 °C)
battery	3 x 1.5 volt AAA
battery life	minimum 5 years (10000 hours)
sensor type	thermistor
display	15 mm LCD
dimensions	32 x 71 x 141 mm
weight	298 grams
<i>FREE traceable certificate of calibration included</i>	