

# SuperFast Thermapen® 3

## digital thermometer

- over 50 % faster response than traditional probes
- FREE traceable certificate of calibration
- reaches temperature in just 3 seconds!
- 2 year guarantee

The SuperFast Thermapen 3 thermometer incorporates a large digital display with a precise read-out of temperature over the range of -49.9 to 299.9 °C with a 0.1 °C resolution and an accuracy of ±0.4 °C. The resolution can be switched to 1 °C, if required, via a switch in the battery compartment. The thermometer will power off automatically after ten minutes, maximising battery life. This feature can be disabled if not required.




The casing is washable and includes 'Biomaster' additive that reduces bacterial growth and the ergonomic rubber seal minimises the risk of the ingress of water, dust or food. As well as being splashproof, it is still 'probably' the fastest reading contact thermometer on the market today. The true temperature of a product can be tested in just three seconds. The Thermapen incorporates a reduced tip, stainless steel, food penetration probe (Ø3.3 x 115 mm) that conveniently folds back through 180° into the side of the instrument when not in use.

Both low battery (icon) and open circuit indication are displayed, when applicable. Each Thermapen is powered by two lithium coin cell batteries with a minimum life expectancy of 1500 hours.



### optional accessories

- zip pouch with belt strap (830-001)
- protective silicone boot (830-260)
- acrylic wall bracket (832-200)
- glow in the dark protective silicone boot with magnets (830-265)
- protective PVC wallet with belt strap (830-110)



order code	description	£ each
231-217	Thermapen 3 - white	40.00
231-227	Thermapen 3 - yellow	40.00
231-237	Thermapen 3 - green	40.00
231-247	Thermapen 3 - red	40.00
231-257	Thermapen 3 - blue	40.00
830-260	protective silicone boot	4.00
830-265	silicone boot - glow in dark	6.50
830-110	protective wallet	5.00
830-001	zip pouch	6.00
832-200	wall bracket	8.50

specification	SuperFast Thermapen 3
range	-49.9 to 299.9 °C
resolution	0.1 °C or 1 °C - user selectable
accuracy	±0.4 °C (-49.9 to 199.9 °C) otherwise ±1 °C
battery	2 x 3 volt CR2032 lithium coin cell
battery life	1500 hours
sensor type	K thermocouple
display	14.3 mm LCD
dimensions	19 x 47 x 153 mm
weight	97 grams
<i>FREE traceable certificate of calibration included</i>	